

Flex-IO Port Functions

- 1: GND
- 2: VCC_UNREG
- 3: PB12 = SPI2 NSS, CAN2 RX
- 4: PB13 = SPI2 SCK, CAN2 TX, USART3 CTS
- 5: PB14 = SPI2 MOSI, TIM12 CH1, USART3 RTS
- 6: PB15 = SPI2 MISO, TIM12 CH2
- 7: PC6 = TIM8 CH1, USART6 TX
- 8: PC7 = TIM8 CH2, USART6 RX
- 9: PC8 = TIM8 CH3
- 10: PC9 = TIM8 CH4

